

# PC104 GPS IO Card Setup

	<b>Jumper X1</b> <b>(2 pin)</b>	<b>Jumper X0</b> <b>(2 pin)</b>	<b>GPS</b> <b>Port1</b>	<b>GPS</b> <b>Port2</b>
<i>(default)</i>	<i>Off</i>	<i>On</i>	<i>3F8-3FF</i>	<i>2F8-2FF</i>
	Off	Off	3E8-3EF	2E8-2EF
	On	On	2F8-2FF	3F8-3FF
	On	Off	2E8-2EF	3E8-3EF

To disable GPS Port2, place a 2 pin jumper across JP4 COMB Enable. The factory default is *ENABLED*.

To set the interrupt number on GPS Port1, place a 2 pin jumper on the appropriate interrupt row across the COMA and IRQ columns. The factory default is *IRQ4*.

To set the interrupt number on GPS Port2, place a 2 pin jumper on the appropriate interrupt row across the COMB and IRQ columns. The factory default is *No Interrupt*.



**Embedded Designs Plus**  
**HC88**  
**Forest Grove, MT 59441**  
(406) 428-2108 p  
(406) 428-2109 f  
[info@embedded-designs-plus.com](mailto:info@embedded-designs-plus.com)